

GUIDE ROLLER INSTALLATION INSTRUCTIONS FOR 10" BELT CONVEYOR INLET

1. Using the template provided with this kit, locate and drill two 7/16" holes in each wind guard mounting plate of the inlet housing. The template should be aligned with the bottom and sides of the mounting plates, as shown. NOTE: Use the top two holes in the template for 60', 70' & 85' conveyors and use the bottom two holes for 35' conveyors.
2. Secure the guide roller assembly to the wind guard mounting plates with four 3/8" x 1" bolts, lockwashers and hex nuts. NOTE: It will make installation easier if the wind guard panel is removed from one side of the conveyor.

