

HEAD COVER

Attach head drive cover using 3/16" x 1/2" stove bolts, lock washers and nuts.



Keep all safety shields and devices in place.

