

INTAKE GUARD FOR 8" AUGER #ASE-12791

Install intake guard assembly at intake end of auger. Slide the assembly over the flighting and the housing. Insert intake stub shaft through the bearing and clamp the assembly to the auger housing. Top upper half band should be above welded stop.

Attach the hitch pipe to intake guard.

*There should be a stop welded to the auger housing between the two top intake guard clamp bands. If the auger has no stop, weld on a 3/8" square bar 1" long or similar part.

